Pinnacle Rubber Wall Base

ROPPE.
Proven. Flooring. Experiences.

Maintenance

- 1. Initial Maintenance
 - Allow 72 hours after installation for proper curing of the adhesives
 - Clean the wall base with a neutral pH cleaner and a soft wet cloth
 - Do not use detergents or abrasive cleaners as they will dull the look of the wall base
 - Avoid repeated contact with vacuums with a beater bar or electric brooms with hard plastic bottoms and no padding as this may cause discoloration, scratching and loss of gloss
- 2. Weekly Maintenance
 - Dust the wall base to remove any dirt or particulates accumulated on the wall base
 - Remove any spills or other large deposits of dirt and / or debris
- 3. Wall Base Protection Devices
 - When moving in appliances or heavy furniture, it is always wise to protect the floor and wall base from scuffing and tears by using something to protect the floor and wall base